




Quick Start Guide

Dual VC Tilt Equaliser

STILTS



Operation

Stilts can be switched seamlessly between two styles of EQ: **Tilt** (with the Mode Switch in the raised position) and **Baxandall High Shelf** (with the Mode Switch latched down)



Tilt Mode

Turn clockwise to simultaneously boost high and cut low frequencies

Turn anti-clockwise to cut highs and boost lows



Baxandall High Shelf Mode

Turn clockwise for a gentle high shelf boost

Turn anti-clockwise to cut highs



For a neutral response adjust the control knob to the central position (12'o clock)

CH 2 audio is normalled from CH 1 if no lead is patched to CH 2 Audio Input

CH 2 CV is normalled from CH 1 if no lead is patched into CH 2 CV input

Both channels have identical circuitry and share the active EQ mode